		N			No.	
			VTA - E2	VCC - E2	IDL - E2	Terminals
(1) • IDL — E2	TP Sensor	No voltage			Trouble	
		IG SW ON				
	ECM (+B1) (E21) (E21) (E21) VTA VCC E1	Throttle valve fully open	Throttle valve fully closed (Throttle opener must be cancelled first)		Throttle valve open	Condition
	2016.9	3.2 - 4.9 V	0.3 - 0.8 V	4.5 - 5.5 V	9 - 14 V	STD voltage

